

**2004 Ford Taurus LX**

2004 SPECIFICATIONS Sable &amp; Taurus

**Torque Specifications****A/C SYSTEM TORQUE SPECIFICATIONS**

<b>Application</b>	<b>Ft. Lbs. (N.m)</b>
A/C Manifold & Tube Assembly Bolt	15 (20)
Compressor Bolts	18 (25)
Compressor Clutch Disc & Hub Bolt	120 (13)
Condenser-To-Evaporator Line Fitting	68 (92)
Evaporator Core Orifice Connection	68 (92)
Instrument Panel Cowl Side Mounting Bolts	30 (40)
Power Steering Pressure Line	27 (37)
Roll Restrictor Bracket Bolt (2V)	18 (25)
	<b>INCH Lbs. (N.m)</b>
A/C-Heater-to-Cowl Nut	44 (5)
Condenser-To-Evaporator Line Bolts	80 (9)
Condenser Core Mounting Bolt	6 (53)
Condenser Core Refrigerant Line Fittings	71 (8)
Fuel Line Bracket Bolt	71 (8)
Heater/Evaporator Core Housing Mounting Bolt	44 (5)
Heater/Evaporator Core Housing Nut	44 (5)
Instrument Panel Finish Screw	26 (3)
Instrument Panel Top Cowl Screws	71 (8)
PCM Mounting Bracket Nut	44 (5)
Peanut Fitting Nut	71 (8)

**BATTERY****BATTERY SPECIFICATIONS**

<b>Item</b>	<b>Specification</b>
Manufacturer	Motorcraft
Voltage	12 Volt
Cold Cranking Amps	540
Amp/Hr Rating	58 (Standard 3.0L 4V), 78 (With Tow Option)

**Torque Specifications****BATTERY TORQUE SPECIFICATIONS**

<b>Application</b>	<b>Ft. Lbs. (N.m)</b>
Ground Cable-To-Body Nut (2V)	18 (25)
Ground Cable-To-Body Nut (4V)	15 (20)
Harness Bracket/Engine Ground Cable Nut	18 (25)
Starter Motor Battery Positive Cable Nut	18 (25)