

Fuel and Oil



Fuel/Oil pressure gauge 002275
 P/N 5000902



Fuel vacuum tester 23286
 P/N 390954



Oil pressure test adapter 002623
 P/N 350930

Gearcase



Gearcase filler 49790
 P/N 501882




Universal pinion bearing remover and installer kits P/N 5005927 and P/N 5005928 33974



Installer handle 002575
 P/N 345822




Gearcase pressure tester 49794
 P/N 507977 (Stevens P/N S-34)
 Gearcase vacuum tester
 P/N 507982 (Stevens P/N V-34)



Gearcase fill/drain adaptor 005517
 P/N 5037486



Prop shaft remover 002630
 P/N 5034237



Dial indicator set



Gearcase fill/drain adaptor 48642
 P/N 772269